### **Quick Guide for MilkPlan tanks**

## Your MilkPlan tank has already been programmed

#### Should you need assistance adjusting the settings please call 800-245-8222 M-F 8am - 4pm

Please read the factory instruction manual provided before using the tank as a few minuets reading the set up instructions can avoid simple problems,

<u>The tank has already been programmed</u> for the optimal settings and parameters will not need to be adjusted unless listed below. If you need assistance please call us at 800-245-8222

When you turn on the tank with milk in it the display will show the current temperature of the milk. The temperature you want the milk to cool to is called the "set point".

## How to see the set point (the temperature the milk will cool to)

- 1. Push and immediately release the SET key: The display will show the Set point value.
- 1 After 3 seconds the display will go back to the current temperature.

# How to change the Set Point

- 1. Push the SET key for more than 3 seconds to change the point Set value;
- 2. The value of the set point will be the displayed and the \* LED starts blinking.
- 3. To change the set point value push UP or DOWN arrows.
- 4. To memorize the new set point value push the SET key again.